

DMX回線表

麻生市民館

No.	名称	備考	No.	名称	備考	No.	名称	備考	No.	名称	備考	No.	名称
1	1B上下-1	作業灯	61	TL上-1		121	FC上-3		166	客席-1	通常客電	205	FD1-1
2	1B上下-2		62	TL上-2		122	FC上-4		167	客席-2		206	FD1-2
3	1B上下-3		63	TL上-3		123	FC上-5		168	客席-3		207	FD1-3
4	1B上下-4		64	TI下-1		124	FC上-6		169	客席-4		208	FD1-4
5	1B中-1	作業灯	65	TI下-2		125	FC上-7		170	客席-5		209	FD1-5
6	1B中-2		66	TI下-3		126	FC上-8		171	客席-6		210	FD1-6
7	1B中-3		67	UH上-1		127	FC上-9		172	客席-7		211	FD2-1
8	1B中-4		68	UH上-2		128	FC上-10		173	客席-8		212	FD2-2
9	2B上下-1	作業灯	69	UH上-3		129	FC上-11		174	客席-9		213	FD2-3
10	2B上下-1		70	UH上-4		130	FC上-12(直)		175	客席-10		214	FD2-4
11	2B上下-3		71	UH中-1		131	FC下-1		176	客席-11		215	FD2-5
12	2B上下-4		72	UH中-2		132	FC下-2		177	客席-12		216	FD2-6
13	2B中-1	作業灯	73	UH中-3		133	FC下-3		178	客席-13		217	FD3-1
14	2B中-2		74	UH中-4		134	FC下-4		179	客席-14		218	FD3-2
15	2B中-3		75	UH下-1		135	FC下-5		180	客席-15		219	FD3-3
16	2B中-4		76	UH下-2		136	FC下-6		181	客席-16		220	FD3-4
17	1S-1		77	UH下-3		137	FC下-7		182	客席-17		221	FD3-5
18	1S-2		78	UH下-4		138	FC下-8		183	客席-18		222	FD3-6
19	1S-3		79	CL-1		139	FC下-9		184	客席-19		223	FD4-1
20	1S-4		80	CL-2		140	FC下-10		185	客席-20		224	FD4-2
21	1S-5(直)		81	CL-3		141	FC下-11		186	客席-21		225	FD4-3
22	1S-6		82	CL-4		142	FC下-12(直)		187	客席-22		226	FD4-4
23	1S-7		83	CL-5		143	前FC-1	★	188	客席-23		227	FD4-5
24	1S-8		84	CL-6		144	前FC-2		189	客席-24		228	FD4-6
25	1S-9(直)		85	CL-7	未使用	145	前FC-3(直)		190	客席-25		229	FD5-1
26	1S-10		86	CL-8	未使用	146	花道FC上-1		191	客席-26	▼	230	FD5-2
27	1S-11		87	CL-9	未使用	147	花道FC上-2		192	客席-27	親子室	231	FD5-3
28	1S-12		88	CL-10	未使用	148	花道FC上-3		193	客席-28	✕	232	FD5-4
29	1S-13		89	CL-11		149	花道FC上-4		194	客席-29		233	FD5-5
30	1S-14		90	CL-12		150	花道FC下-1		195	客席-30		234	FD5-6
31	1S-15		91	CL-13		151	花道FC下-2		196	客席-31		235	FD6-1
32	1S-16		92	CL-14		152	花道FC下-3		197	天反-1(上)		236	FD6-2
33	2S-1		93	CL-15		153	花道FC下-4		198	天反-1(中)		237	FD6-3
34	2S-2		94	CL-16		154	LH上-1		199	天反-1(下)		238	FD6-4
35	2S-3		95	CL-17	未使用	155	LH上-2		200	天反-2(上)		239	FD6-5
36	2S-4		96	CL-18	未使用	156	LH上-3		201	天反-2(中)		240	FD6-6
37	2S-5(直)		97	CL-19	未使用	157	LH上-4(直)		202	天反-2(下)		241	FD7-1
38	2S-6		98	CL-20	未使用	158	LH中-1		203	天反-3(上)		242	FD7-2
39	2S-7		99	FS上-1		159	LH中-2		204	天反-3(下)		243	FD7-3
40	2S-8		100	FS上-2		160	LH中-3					244	FD7-4
41	2S-9		101	FS上-3		161	LH中-4					245	FD7-5
42	2S-10		102	FS上-4		162	LH下-1					246	FD7-6
43	2S-11		103	FS上-5		163	LH下-2					247	FD8-1
44	2S-12		104	FS上-6		164	LH下-3					248	FD8-2
45	3S-1		105	FS上-7		165	LH下-4(直)					249	FD8-3
46	3S-2		106	FS上-8								250	FD8-4
47	3S-3		107	FS下-1								251	FD8-5
48	3S-4		108	FS下-2								252	FD8-6
49	3S-5		109	FS下-3								253	FD9-1
50	3S-6		110	FS下-4								254	FD9-2
51	3S-7		111	FS下-5								255	FD9-3
52	3S-8		112	FS下-6								266	FD9-4
53	SP-1		113	FS下-7								257	FD9-5
54	SP-2		114	FS下-8								258	FD9-6
55	SP-3		115	F-1								259	FD10-1
56	SP-4		116	F-2								260	FD10-2
57	SP-5		117	F-3								261	FD10-3
58	SP-6		118	F-4(直)								262	FD10-4
59	SP-7		119	FC上-1								263	FD10-5
60	SP-8		120	FC上-2								264	FD10-6

★下袖前にコンモあります。
奥への延長ケーブルも
引き回してあります。

※(直)・・・調光⇄直 切り替え可能回路

※FD=LED LH